




4



5





6






7

40"-43"



49"-75"



SAMSUNG

NU7102 NU7120 NU7140 NU7170


Краткое руководство по установке
QUICK SETUP GUIDE

Жылдам орнату нұсқаулығы

Короткий посібник зі встановлення


O'rnatish bo'yicha qisqacha qo'llanma






40"-50"


1



2




3




55"


1



2




3




65"-75"

1



2



3

